

Dane aktualne na dzień: 25-10-2026 10:08

Link do produktu: <https://www.taniosat.pl/pilot-tv-lg-oryginalny-uniwersalny-26lc41-32lc41-37lc41-42lc4-mkj32022835-p-17616.html>



Pilot TV LG oryginalny uniwersalny 26LC41 32LC41 37LC41 42LC4 MKJ32022835

Cena	149,99 zł
Numer katalogowy	ATL11835
Kod producenta	ATL11835
Kod producenta	ATL11835
Marka	LG
Waga produktu z opakowaniem jednostkowym	0.3
Kolor	czarny
Przeznaczenie	TV
Model	MKJ32022835
Symbol baterii	AAA (R3)
Zawiera baterie	nie
Certyfikaty zgodności	CE

Opis produktu

Pilot jest zgodny z następującymi modelami telewizorów LG:

- 26LC41
- 26LC42
- 26LC43
- 26LC44
- 26LC45
- 26LC46
- 32LC41
- 32LC42
- 32LC43
- 32LC44
- 32LC45
- 32LC46
- 37LC41
- 37LC42
- 37LC43
- 37LC44
- 37LC45
- 37LC46
- 42LC41

-
- A black LG remote control is shown diagonally against a white background. The remote features a variety of buttons: a top row with 'INPUT TV', 'INPUT', 'POWER' (a green button with a power symbol), and 'MODE TV'; a row below with 'RATIO', 'SLEEP', 'TEXT', 'DVD', and 'VCR'; and a row with 'SIMP LINK', 'EXIT', 'LIST', 'MENU', 'Q.VIEW', and a red button. The center of the remote has a circular navigation pad with an 'OK' button in the middle, surrounded by four directional arrows. To the left of this pad are 'VOL +', 'VOL -', 'FAV', 'MUTE', and 'PR +'. To the right are 'EXIT', 'LIST', 'MENU', 'Q.VIEW', and an asterisk button. Below the navigation pad is a numeric keypad with buttons for 1 through 9, 0, and a '10' button. At the bottom left, there are buttons for 'TIME', 'SIZE', 'REVEAL', 'UPDATE', 'HOLD', and 'INDEX'. The LG logo and the model number 'MKJ59170805' are printed at the bottom left of the device.

